


BT-7600P PARTS

ASSEMBLY INSTRUCTION

(1)X1



(9)X8



M6*20mm

(2)X1(L)X1(R)



(10)X4



M6*18mm

(3)X1



(11)X4



6.5*18*1.5mm

(4)X2




(12)X2




M8*25mm


(5)X1




(13)X1



(6)X1




(14)X1




M5

(7)X1



(15)X1



M6


(8)X1




(16)X1




①




③




②



④



⑤



⑥

