\RE AND MAINTENANCE

ot clean using a mild water-free solvent. Only a professional cleaner should dertake a complete overall cleaning.

e use of steam or water-based cleaners may cause excessive shrinking or staining.

OTICE

lease make sure that you have all parts indicated before you begin assembly of this

This item should be assembled on a soft surface to prevent scratching the finish ring assembly

his item may require periodic tightening


Part List and Hardware List

		Allen key	
		Flat washer	Н3
		Spring washer	H2
		Allen bolt L	<u> </u>
	l P 1	Back leg-2	т
		Back leg-1	D
		Front leg-2	C
		Front leg-1	В
F		SEAT	Þ
PICTURE		NOJEJEJSETE	=10=

SAFAVIEH RURNITURE

Model# MCR4704

Product Dimensions:20.07 W x 24.61D x 34.84 H



REPARATION

fore beginning assembly of product, make sure all parts are present. Compare parts with package contents list and rdware contents list.

any part is missing or damaged, do not attempt to assemble the product. timated Assembly Time: 10 minutes.

ols Required for Assembly (included): Allen Key

