





# HOOKER<sup>®</sup>

## — FURNITURE —

### ASSEMBLY INSTRUCTION

Item#: 5820-10458-84 Writing Desk

\*\*\* **Caution: Please read all instructions carefully before starting the assembly process. This unit is heavy and can best be assembled with the help of two or more people.**

NO	HARDWARE LIST		Q'TY
A		ALLEN BOLT	8
B		LOCK WASHER	8
C		FLAT WASHER	8
D		ALLEN WRENCH	1





Diagram 1

#### **Assembly Steps:**

1. Remove two side drawers, place desk top upside down on a soft surface to prevent from scratching top.
2. Follow numbers on legs and corners blocks . Attach legs to desk top using 2 bolts(A), 2 lock washers (B), 2 flat washers (C), by turning with allen wrench (D) in a clockwise direction (see diagram 1).
3. Turn writing desk upright and put two drawers back.

**Cleaning Instruction: Clean finished parts with a mild dishwashing liquid and water solution on a damp cloth. Polish the finish with soft cloth and an industry recognized furniture polish.**