

Installation Guide

Waterfall Faucet

Certifications & Information

- ADA Approved
- · Limited Lifetime Warranty

Flow Rate

1.58gpm at 60PSI

Tools

Gather the necessary tools as shown to complete the installation of this faucet.



Teflon Tape (Included)



Safety Glasses



Adjustable Wrench




Phillips Screwdriver




Flashlight

Configuration



^{*} This measurement is only suggestive and may vary according to the sink model.



Connect to water supply lines with TWO 3/8" Compression Faucet Connectors (Included)




Installation Guide 1

Faucet Installation


- A. Turn off the water supply. Remove the faucet with the mounting hardware attached from the package.
- B. Remove all mounting hardware from the coup.


- C. Insert the coup of the faucet body into the hole of the sink deck.
- D. From the underside of the sink or mounting surface, attach the rubber ring, followed by the steel ring and the brass lock nut. Hand-tighten the lock nut until secure.
- E. With a phillips screwdriver, work around the brass nut, tightening each of the three screws in turn until all are secure.
- F. Attach a 3/8" compression faucet connector to the end of each corresponding water supply line.
- G. Attach the opposite end of each hose to the corresponding water supply lines by tightening the 3/8" compression fittings onto the lines. Secure all fittings with a 1/4 turn of a wrench.



Important 🛆

Turn on the water supply SLOWLY, to test for leaks before completely opening the water lines.






To prevent damage to the tube body, tighten the connections by carefully using two wrenches as shown. Use caution to not bend the stem.

Check for leaks.

Maintenance & Cleaning

The faucet can be cleaned by rinsing with clear water or washing with mild detergents. Dry the faucet with a clean, soft cotton cloth.

CAUTION: do not use any cleaning agents containing acids, abrasives, or other harsh chemicals.



Simply rinse and dry faucets with a soft towel every week to prevent mineral deposits from forming. Clean spills and splatters as they happen. Do not let soap, toothpaste or other contaminates dry on the faucet, this can stain or pit the finish. Use a mild soap and soft sponge or towel to remove residue. Rinse and dry thoroughly.



Never use an abrasive cleaner or rough sponge to clean or dry your faucet. Harsh cleaners could dull or scratch the finish. Use only a soft disinfectant that does not contain bleach or chlorine and apply with a soft towel.



www.mrdirectint.com sales@mrdirectint.com 1-877-946-5725

Notes

Warranty Information

MR Direct warrants to the original consumer purchaser that our sinks and faucets will be free from defects in material and workmanship under normal use for the lifetime of the product. MR Direct may elect to repair or replace any defective MR Direct product covered by our warranty.

Our warranty does not cover defects caused by misuse, abuse, negligence, alterations, environmental conditions, improper installation, storage and handling; nor any labor expenses.

From time to time we will change design specifications and materials as conditions require and improvements are developed. We have no obligation to incorporate such changes in products we previously manufactured.

This warranty is in lieu of any and all other warranties, express or implied, including any warranties of merchantability and of fitness for a particular purpose; and excludes any incidental or consequential damages. No representative has the authority to change or enlarge the above warranty.

This warranty is only valid in the United States of America. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusion may not apply. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

One-Year Accessory Warranty

MR Direct warrants to the original purchaser that all of our accessories will be free from defects in material and workmanship under normal use for one full year.

Our warranty does not cover defects caused by misuse, abuse, negligence, alterations, environmental conditions, improper installation, storage and handling; nor any labor expenses. MR Direct may elect to repair or replace any defective MR Direct accessory covered by our warranty.

Installation Guide 4