




ITEM# RV-F0388 / RV-F920388

IMPORTANT SAFETY INSTRUCTIONS

- To avoid injury or damage, mount only on a surface that is sturdy.
- To avoid electric shock, make sure electricity is turned off at the main circuit breaker panel. If you are replacing an existing fixture, turn off the following in order: fixture, wall switch, and main fuse or breaker box. Note: Some types of fuses must be unscrewed to shut the power off.

! For any replacement parts or installation issues, please email service@revel-home.com

Unpack the Lamp: Check the contents of the box. Box should contain all items below.



Enjoy your new lamp!