

ASSEMBLY INSTRUCTION






Sunpan Product Name: **EMMIT BED - KING**

Please visit our website www.sunpan.com for more great products.

For assembly questions please call **1-800-787-1019 (or +1-416-736-0094)** outside North America or email to info@sunpan.com

PARTS LIST			
Before you begin, please layout all parts and ensure you have the correct count.			
PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION
A	Metal L-Plate A	4	
B	Metal L Plate B	4	
C	Metal L Plate C	10	
D	Screws (Ø8*30mm)	32	
E	Wood screw(Ø5*40mm)	30	
F	Washer	10	
G	Nut(Ø10mm)	4	
H	Cabinet leg	4	
I	Allen Key	1	
J	Regulating foot	4	

ASSEMBLY INSTRUCTIONS

STEPS	DESCRIPTION	ILLUSTRATION
1	① Use wood screws (E) to install Metal L-Plate C (C).Then,stick the washer (F) on the top of Metal L Plate C (C)	
2	② Fix Metal L-Plate A (A) and Metal L-Plate B (B) with screws (D) by using Allen Key (I). Install cabinet leg (H) by Metal L-Plate B (B) and Nut(G)	
3	Attached screws (D) to regulating foot (J)	

ASSEMBLY TIPS:

Please check parts and hardware before assembling. Follow each instruction step by step.

Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.

Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.

Please follow instructions in the sequence as numbered to assure fast/easy assembly.

WARNING:

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement.

Keep all hardware parts out of the reach of children.

FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:

Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.

Excessive exposure to sunlight may cause fading.

Excessive temperature and humidity or cold may cause cracking or splitting.

Dust with a clean, damp, lint free cloth.

Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.

Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.