



# EVAPORATIVE AIR COOLER

## USER MANUAL

FOR MODELS:  
PEVP560



Before using your air conditioner, please read this manual carefully and keep it for future reference, along with your receipt.



## **SAFETY INSTRUCTION**


1. Non-specialized personnel or unauthorized repair personnel shall not to repair or modify the machine.
2. It is forbidden to operate with wet hands to avoid electric shock.
3. Any power cord, which suffers from aging and knotting and whose plug is damaged, should be stopped its use immediately, and must be repaired by a professional manufacturer or equally qualified personnel.
4. No cleaning, maintenance or movement of the unit is allowed if it does not switch off.
5. If the unit is not in use for a long time, unplug the power cord.
6. To prevent accidental injury or damage to the unit, please do not insert any foreign matter into the air inlet and outlet, because the unit incorporates a high-speed wind rotor,
7. It is prohibited to use this unit in environments with flammable and explosive gases and direct sunlight for a long period shall be avoided.
8. Do not place this unit in an inclined or other uneven place to prevent the unit from falling and causing damage to the unit or internal parts.
9. This machine is suitable for indoor use instead of outdoor use.
10. At any time the water level in the tank shall not exceed "MAX" (maximum) scale, and during humidification, the total water level in the tank shall be controlled, and shall not be below "MIN" (minimum) scale.
11. After the water tank is filled with water, do not tilt or collide with the unit when placing or moving it. To move the unit body, please drive it slowly from the side to prevent water overflow.
12. In using the unit, prohibit overturning to avoid any accident. If the unit topples over accidentally, and it contains water, unplug the power cord immediately and take it to repair store.
13. Do not place items on the unit, and covering the outlet is strictly prohibited.
14. When wash the unit appearance, apply a damp cloth (or add a little cleaning agent) to wipe, and never use corrosive cleaning agent or solvent for cleaning. Never rinse the unit with water.

15. Do not have the air inlet and outlet of the unit close to walls, curtains and other objects, or they may block the airflow and affect air supply.
16. When the unit is running, do not knock at or shock the unit body forcibly or it may lead to automatic shutdown, in which case simply restart the unit.
17. In summer, the water in the tank may easily deteriorate and generate odor, please pay attention to regular change of water; if the indoor temperature is below zero in winter humidification, it is best to use warm water for humidification.
18. Do not place the unit directly below the power outlet.
19. Do not use the unit around the tub, sprinkler or swimming pool.
20. Product repair must be carried out in a designated agency.
21. If the supply cord is damaged, it must be replaced by manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
22. Indoor use only.
23. To protect against the risk of electrical shock, do not immerse the unit, cord or plug in water or other liquid.
24. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Young children should be supervised to ensure that they do not play with the appliance.
25. When the appliance is not in use and before cleaning, unplug the appliance from the outlet.
26. Keep electrical appliances out of reach from Children or infirm persons. Do not let them use the appliances without supervision.
27. Unplug the appliance during filling and cleaning.
28. Prior to cleaning or other maintenance, the appliance must be disconnected from the supply mains.
29. Use a soft cloth moisten with mild soap, and then use a dry cloth to wipe it again.


# INSTALLATION INSTRUCTIONS

## ■ Name of components

Installation of the water tank:





## Foot-Wheel Installation



## INSTRUCTIONS FOR USE


### ■ Instructions for key of remote controller



Considerate Hint:

1. Effective Range of Remote Control: within 5m distance and 30-degree deflection in front of Product.

## ■ Instructions for operation of body



Press a key on the unit to activate a corresponding function.

For instance:

- Press [OSC.] Key to activate or deactivate Swing Function.  
(Note: Manual horizontal blade allows tilting flow direction.)
- Press [SPEED] Key to adjust 3 speeds of air flow.
- Press [STYLE] Key to switch between Normal, Natural and Sleep Functions.
- Press [TIMER] Key to set 1–12 hour timer setting.
- When [EVA./COOLER] Key is pressed, the indicator lights up constantly if the operation is normal; when the indicator flashes, it denotes a water shortage, please add water immediately.


Considerate Hint:

Push Buttons on the unit may differ based on the actual product model.

## ADD WATER

Add water from top: Rotate water tank's top cover, fill in water.

Add water from side: Rotate water tank's side cover, fill in water.



### Considerate Hint:

- When humidifying, water level in the Water Tank must remain under MAX indication; replenish water if level gets lower than MIN indication.
- The water level in the tank is below minimum scale marked on water display window, don't use the humidification function.
- When the tank water level is lower than the minimum scale, the unit shall make 3 seconds buzzing warnings sound, then the water pump stop running, this time need add water to run humidification function.
- When the tank water level exceed the maximum, the unit shall make 10 seconds buzzing warnings sound, to prevent the water in a water flooded lead to overflow

## TROUBLESHOOTING

In case the product cannot be operated normally after installation, checks shall be made for items described bellow:

1. Power cable unplugged or faulty contact.
2. Power Switch on the back of product or in the display panel not switched on.

If product remains dysfunctional after checking, a local dealer shall be sought for assistance.

## MAINTENANCE



Make sure power supply is disconnected before cleaning the product.



Never wash the unit in water. For cleaning, remove components (water tank, honeycomb filter, etc.) and clean them with water and soft brush. Allow them to air-dry before re-assembling.



Never clean the product with any abrasive tool or solvent. Clean with detergent and wipe dry with cloth immediately.



Never dismantle the product or attempt to make any modification. Regular check and cleaning of the product is recommended for prolonging its lifespan.



**Distributed by:**

Perfect Aire, LLC  
5401 Dansher Rd.  
Countryside, IL 60525

**844-4PA-AIRE | 844-472-2473**  
**[www.perfectaire.us](http://www.perfectaire.us)**

PA/User\_1PAQ8000/09172018

Specification and performance data is subject to change without notice.

Printed in China