

















WL-

# Model 738AV

## Assembly Instructions

### Parts Listing

- |              |   |               |   |
|--------------|---|---------------|---|
| A            |  | B             |  |
| 16PCS        |   | 4PCS          |   |
| C            |  | D             |  |
| 4PCS         |   | 8PCS          |   |
| E            |    | F             |    |
| 2PC          |   | 2PC           |   |
| G            |    | H             |    |
| LEFT<br>1PCS |   | RIGHT<br>1PCS |   |
| I            |    | J             |    |
| 1PCS         |   | 1PCS          |   |
| K            |    |               |   |
| 1PCS         |   |               |   |



**ASSEMBLY NOTES:**  
During assembly, hand tighten screws only. When all screws are in place, you may then tighten all screws completely.  
**CAUTION:** 1. Do not use this chair as a step ladder.  
2. Check for loose screws and tighten them anytime.