### ASSEMBLY INSTRUCTIONS

#### ATTENTION:


(For LD1031L-42)

- 1. Please read these instructions carefully before assembly.
- 2. Aluminum is soft metal over tighten may strip threads or break the part.
- 3. DO NOT use power tools.
- 4. Check parts against the parts list to make sure you have all parts needed for proper assembly.
- 5. Familiarize yourself with the inventory of parts and the accompanying illustrations to ensure safe and proper assembly.

#### Assembly steps:

- 1. Turn the table top(A) upside down on the soft clean surface.
- 2. Loosely attach the 4 legs(C) to the table top with big flat washers(F), big lock washers(E),big bolts(D),nuts(L) and nut caps(M).
- 3. Loosely attach each of the center plate(B) to the legs. Note that the recessed end of each plate goes on the leg last at each corner. Secure using small flat washers(H), small lock washers(I), small bolts(G) and PVC covers(J).
- Turn the table onto its legs and put center tray (A1)on the table top. Use the adjuster feet to level the tables.
  Tighten all the bolts and nuts completely. DO NOT over tighten the nuts and bolts.
- 6. Turn the table onto its legs and use the adjuster feet to level the tables.

Warning: please do not use acid or alkaline washing liquid to clean the product.



Parts list	Parts picture	Description	Qty		Parts list	Parts picture	Description	Qty	
А		Table top	1		D	(M8*30)	Big bolt	4	
					F	(M8)	Big flat washer	4	
A1		Center tray	1		E	(M8)	Big lock washer	4	
					L	(M8)	Nut	4	
В		Center plate	2		М	$\Theta$	Nut cap	4	
					G	(M6*35)	Small bolt	8	
С		Table leg	4		Н	(M6)	Small flat washer	8	
			_		ı	(M6)	Small lock washer	8	
0		Basin	1		J	ф	PVC cover	8	
Р	4	Adjustable Foot	Factory already assembled		K		Wrench	1	
					N	2 <u>s</u>	Wrench	1	

Made in China

**\*DO NOT OVER TIGHTEN** 

**\*NO POWER TOOLS** 







# **ASSEMBLY INSTRUCTIONS**

(For LD5052-7)

Parts List							
Pieces	Schema	Description	QTY				
Α	(M8*45)	Screw	4				
В	(M8)	Flat washer	8				
С	(M8)	Lock washer	4				
D	(M8)	Nut	4				
Е	Ш	Nut cap	4				
G	23	Wrench	1				
Н	•	Adjustable Foot	Factory already assembled				
I		Seat	1				
J	A	Base	1				



#### **WARNING!**

OThis chair has a 250 lbs weight capacity.

OHang cushion over chair frame to dry if it gets wet to prevent mold/mildew.

#### ATTENTION:

- 1. Please read these instructions carefully before assembly.
- 2. Aluminum is soft metal over tighten may strip threads or break the part.
- 3. DO NOT use power tools.
- 4. Check parts against the parts list to make sure you have all parts needed for proper assembly.
- 5. Familiarize yourself with the inventory of parts and the accompanying illustrations to ensure safe and proper assembly.




- Place the base on a flat, solid surface.
   Loosely attach the seat to the base.
   Please using screws(A), flat washers(B),
   lock washers(C), nuts(D) and nut caps(E).
- 2. Tighten all the bolts and nuts completely. Use the adjuster feet to level the legs.
- 'Warning DO NOT use acid or alkaline washing liquid to clean the product.

**\* DO NOT OVER TIGHTEN** 

**\*NO SOCKET DRIVERS** 









# **ASSEMBLY INSTRUCTIONS**

(For LD8176-7)

Parts List							
Pieces	Schema	Description	QTY				
Α	(M8*35)	Screw	4				
В	(M8)	Flat washer	8				
С	(M8)	Lock washer	4				
D	(M8)	Nut	4				
E	Ш	Nut cap	4				
G	5_3	Wrench	1				
Н	•	Foot leveler	Factory already assembled				
I		Seat	1				
J	舟	Base	1				
K		Seat Cushion	1				



#### WARNING!

O This chair has a 250 lbs weight capacity.

O Hang cushion over chair frame to dry if it gets wet to prevent mold/mildew.

### ATTENTION:

- 1. Please read these instructions carefully before assembly.
- 2. Aluminum is soft metal over tighten may strip threads or break the part.
- 3. DO NOT use power tools.
- 4. Check parts against the parts list to make sure you have all parts needed for proper assembly.
- 5. Familiarize yourself with the inventory of parts and the accompanying illustrations to ensure safe and proper assembly.