

3.Fixed the small screw in the base ,fasten the tap and the connecting pipe. Then adjust the cover to the base. 4.Remove the areator, turn on the water , then flush the faucet and check for the leaks. If ok, then turn off the water and