













Corner Housewares
3665 A Rt 112 Covert, NY 11727
866-304-5356




A  1pc	B  2pcs	C  2pcs
D  2pcs	1  16pcs	2  16pcs
3  16pcs	4  2pcs	5  1pc


www.cornerhousewares.com
contact@cornerhousewares.com

PRODUCT WARRANTY
Corner Housewares offers replacement of items and parts with factory defects within one year of dated sales receipt. Customers may call toll free, (866) 304-5356


Step 1



Step 2



Step 3



Step 4

