

Assembly Instructions for item: 2211, 2251 Wands Series - 2-Arm LED Sconce, Champagne Wands - 2-Arm LED Sconce

Important: Always disconnect the power before installing or replacing bulbs and before cleaning or other maintenance.

This light should be installed by a licensed electrician

Note: This fixture is not dimmable. Do NOT use with dimmer switch.

LAMP INSTALLATION AND ASSEMBLY

- 1. Shut off power to the outlet box. (fig. A)
- 2. Make appropriate electrical connections using wire nuts:
 - a. Connect the LED driver's live wire (brown/black) to the live outlet box wire.
 - b. Connect the LED driver's neutral wire (blue/white) to the neutral outlet box wire.
 - c. Connect fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate using the green screw (included).
 - d. Carefully place connections in outlet box.
- 3. Attach the mounting plate to the outlet box, secure with outlet box screws.
- 4. Attach the back plate to the mounting plate, secure with mounting screws.
- 5. Restore power to the fixture.

CARE INSTRUCTIONS

Dusting — Use a clean, dry cloth. Cleaning — To protect the finish, avoid any harsh abrasives or chemicals.

2211: Fingerprints on the acrylic can be removed with rubbing alcohol.





