

MADISONPARK®

ASSEMBLY INSTRUCTIONS

Description: BEAUMONT COFFEE TABLE





Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.






Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description		QTY
P1	Table Top		1
P2	Tray		1
P3	Metal Leg A		1
P4	Metal Legs B		2

Hardware List


Item	Description		QTY
H1	Bolts Ø1/4" x 3/4"		10
H2	Bolts Ø1/4" 1-3/8"		4
H3	Lock Washers Ø1/4"		14
H4	Flat Washers Ø1/4"		14
H5	Allen Wrench		1

DISCLAIMER:
WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Assembly Procedures:


Step 1: Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach two Metal Legs B (P4) to Metal Leg A (P3) as shown below.

- (H1)x2 Bolts Ø1/4" x 3/4"
- (H3)x2 Lock Washers Ø1/4"
- (H4)x2 Flat Washers Ø1/4"
- (H5)x1 Allen Wrench




Step 2: Loosely attach Tray (P2) to Metal Leg A (P3) and Metal Legs B (P4) as shown below.

- (H2)x4 Bolts Ø1/4" x 1-3/8"
- (H3)x4 Lock Washers Ø1/4"
- (H4)x4 Flat Washers Ø1/4"
- (H5)x1 Allen Wrench




Step 3: Attach Metal Leg A (P3) and Metal Legs B (P4) to Table Top (P1) as shown below.
Securely tighten all bolts by Allen Wrench (H5).


- (H1)x8 Bolts Ø1/4" x 3/4"
- (H3)x8 Lock Washers Ø1/4"
- (H4)x8 Flat Washers Ø1/4"
- (H5)x1 Allen Wrench



Step 4: Turn the assembled table to an upright position. Assembly is complete.



To adjust the adjustable leveler. If there is a gap between a leg and the floor, please adjust the adjustable leveler up or down under each leg.



ADDITIONAL NOTE ABOUT SAFETY:
BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE.
THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY,
AND ENSURE STABILITY.

Thank you for your purchase