

436-10-158 ASSEMBLY INSTRUCTIONS

PARTS LIST			HARDWARE LIST			
A	TOP	1 PC	1		NUT	8PCS
B	LEG	4 PCS	2		LOCK WASHER	8PCS
			3		FLAT WASHER	8 PCS
			4		SPANNER	1 PC

1> Pull out the drawers of the Top (A).

2> Turn the top (A) upside down on a soft flat surface.

3> Insert the legs (B) into the corner blocks of top (A).

4> Assemble the corner block to Leg (B) with Nuts (1) + Spring Washer (2) + Flat Washer (3)

