


# DECOROTIKA



## **Classy Tv Stand** assembly guide

01



Valued Customer,

We design and carefully manufacture our products for our customers. We wish that our customers to have fun while they are doing their new furniture

The product you just purchased was subjected to all sorts of tests and controls before sending out to you.

Hope you enjoy your new furniture!!!

Before starting, please check all components and accessories according to the provided list. If you purchased more than one product, to prevent confusion, be sure that you completed the first product, then start the next one. Please make sure that you select correct numbered part and use specific connector to assemble. We do not recommend any modification or rotation in assembly. Please follow the manual carefully.

Furniture parts are going to several manufacturing procedures. During this process, parts can have little dust or marks. Please clean the parts with damp cloth before assembly to get the best result. Usual cleaning would be suffice.




Although all products are carefully manufactured and packed, sometimes we experience damage during transportation. In such cases, please check the damaged part, note the part number written on the part and do not hesitate to contact us

e-mail: [sales@decorotika.com](mailto:sales@decorotika.com)  
Phone: (201) 282-1510


Do not use your furniture for out of purposes. If you would like to use it out of purpose or would like to do some modification or rotation, please contact us for more details.

Please do not expose your furniture with excessive heat, cold and humidity because product can be affected negatively.


## before you start



Get required installation tools prepared.













Do not install the product on rough surfaces.




Get help from someone else!



# ACCESSORY LIST


<b>A02</b> minifix head  6x	<b>A03</b> minifix screw  6x	<b>A40</b> nail  24x	<b>A12</b> 50 mm screw  6x
<b>A06</b> 18 mm sticker  6x	<b>A09</b> 3.5x18 screw  52x	<b>Z29</b> 160 mm handle  2x	<b>Z39</b> foot  5x
<b>A07</b> 14 mm sticker  6x	<b>T25</b> slider wheel  8x		

## GENERAL VIEW




# getting familiar with the main components

\*Minifix is the main connection component used in Decorotika products. Before starting, please check the below figures




MINIFIX  
HEAD




MINIFIX  
SCREW



DOWEL




\*Please notice that there is an small arrow on A02 (minifix head). This arrow should show the direction of upper hole.




\*A02(minifix head) and A03(minifix screw) help us to attach two wood pieces each other.

\*After attaching two pieces please turn the A02 (minifix head) clockwise direction just a half tour with the help of a screwdriver.




\*Please do not over screw the A02 (minifix head) since it may be broken if too much power is imposed. Just make sure that it is screwed to the direction “+” do not go any further.




# 1 a.inserting components

- \*Please insert A03 (minifix screw) into the holes on the piece #2 as shown
- \*Please insert A02 (minifix head) into the holes on the pieces #4 and #3 as shown
- \*Make sure that all the arrows on A02 (minifix head) are in correct direction



# 2 b.installing main body

- \*Please attach the pieces #a and #3 to the piece #2 as shown below
- \*Now screw the A02 (minifix head) clockwise direction with the help of screwdriver.




3

## c.installing main body

\*Please put the piece #1 as shown below

\*Please turn the A12 (50 mm screw) clockwise direction with the help of an scrediver




4

## d.installing the furniture feet

\*Please put the Z39 (furniture feet) on the pre-drilled holes as shown below.

\*Please turn the A12 (50 mm screw) clockwise direction with the help of a screwdriver.

\*Please install the middle foot to prevent future bending of furniture.




5

# 5

## e. installing sliding wheels

\*Please put the T25 (sliding wheel) on the pre-drilled holes.

\*Then turn all A09 (3.5x18 screw ) clockwise direction with help of an screwdriver.




# 6

## f. installing the handles of sliding doors

\*Please put the Z29 (handle) as shown below

\*Please put the A09 (3.5x18 screw) behind the piece #5

\*Then turn all A09 (3.5x18 screw ) clockwise direction with help of an screwdriver.






7

## g.installing sliding doors

\*Please take the first door and put the lower wheels into inner channel.After the lower wheels placed on the inner channel ,push down the upper wheels then place the door.


\*Please take the second door and put it outer channel.After the lower wheels placed on the outer channel ,push down the upper wheels then place the door.



8

## g.adjusting wheel tightness

\*There is a bolt and nut on the T25 (sliding wheel).You can adjust the tightness of the door by screwing the bolt down.




9

## h.attaching the back panel

\*Please take the panel and nail down with the help of a hammer

\*For the best result use all nails given in the hardware pack





10

## i.placing the stickers

\*For the best appearance of your furniture please place all A06(18 mm sticker) onto the A02 (minifix head).

\*For the best appearance of your furniture please place all A07(14 mm sticker) onto the A12 (minifix head)



Have you seen our other products?

[www.decorotika.com](http://www.decorotika.com)