

ASSEMBLY INSTRUCTIONS



Sunpan Item No: **107332**
Sunpan Product Name: **NAXOS COFFEE TABLE-Carrara White Marble/ Smoked Glass/ Rustic Bronze**
Please visit our website **www.sunpan.com** for more great products .
For assembly questions please call **1-800-787-1019(or +1-416-736-0094)** outside North America or e-mail to **info@sunpan.com**



PARTS LIST			
Before you begin, please layout all parts and ensure you have the correct count			
PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION
A	MARBLE TOP	1	
B	METAL FRAME	1	
C	GLASS SHELF	1	
D	GLASS SHELF SUPPORT (Pre-attached)	2	
E	BOLT (M8X15MM)	4	
F	LOCK WASHER (M8)	4	
G	FLAT WASHER (M8x22MM)	4	
H	BOLT (M6X35MM)	6	
I	ALLEN KEY (4MM)	1	
J	LOCK WASHER (M6) (pre-attached)	6	
K	FLAT WASHER (M6x18MM) (pre-attached)	6	

ASSEMBLY INSTRUCTIONS

STEPS	INSTRUCTION	ILLUSTRATION
1	<p>Before begining assembling, Need to take off 2 pieces of Glass Shelf Supports(D) which are bolted from Metal Frame(B) by using Allen Wrench(I) to disconnect 6 pices of each Bolt(H), Flat Washer(K) and Lock Washer(J).</p> <p>* Note: Please DO NOT remove PE foam wrapped on the posts until glass shelf has been installed.</p>	<p>The illustration shows the process of removing glass shelf supports (D) from a metal frame (B). At the top, a detailed inset shows a close-up of a support (D) being detached from the frame (B). An Allen wrench (I) is used to turn a bolt (H) that passes through a lock washer (J) and a flat washer (K) into the support (D). A curved arrow indicates the direction of rotation. Below this, a larger diagram shows the metal frame (B) with several supports (D) still attached. A large downward arrow indicates the next step, which is shown at the bottom: the metal frame (B) with all supports (D) removed, leaving a clear oval opening.</p>

ASSEMBLY INSTRUCTIONS

STEPS	INSTRUCTION	ILLUSTRATION
2	<p>With the help of another person, Turn over the Metal Frame(B), Put the Glass Shelf(C) in the Metal frame(B) from the bottom side of the Metal Frame(B).</p> <p>Make sure the bottom side of Glass Shelf (C) that has anti-slip buttons is down when putting the Glass Shelf(C) in the Metal Frame(B).</p> <p>* Note: Please DO NOT remove PE foam wrapped on the posts until glass shelf has been installed.</p>	
3	<p>With the help of another person. Lift the Glass Shelf(C) in the Metal Frame(B).</p> <p>Using the Allen Key(I), Bolt (H) ,Lock Washer (F) and Flat washer (G) to assemble the 2pcs Glass Shelf Support(D) to the Metal Frame(B). Do not tighten all bolts untill all Bolts(H) are attached.</p> <p>Make sure the bottom side of Glass Shelf Support (D) down when assembling, the side with floor levelers is bottom side</p> <p>6 pcs Bolt(H) 6 pcs Lock Washer(J) 6 pcs Flat Washer(K)</p>	
4	<p>Stand the Metal Frame(B) up, with the help of another person. Put the Marble Top(A) on the Metal Frame(B).</p> <p>Using the Allen Key(I), Bolt (E), Lock Washer (F), Flat Washer (G) to assemble Marble Top(A) to Metal Frame(B). Do not tighten all bolts(E) Untill all Bolts(E) are attached.</p> <p>4 pcs Bolt(E) 4 pcs Lock Washer(F) 4 pcs Flat Washer(G)</p>	

ASSEMBLY INSTRUCTIONS		
STEPS	INSTRUCTION	ILLUSTRATION
5	Should your floor surface be uneven you can improve the stability by simply turning your table over and adjusting the levelers found under the base.	
6	Your table is now complete and ready for use.	

ASSEMBLY TIPS:

Please check parts and hardware before assembling. Follow each instruction step by step.
 Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.
 Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.
 Please follow instructions in the sequence as numbered to assure fast/easy assembly.

WARNING:

Don't attempt to repair or modify parts that are broken or defective. If you find a broken part please contact us for replacement.
 Keep all hardware parts out of the reach of children.

FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:
 Do not expose your furniture to direct sunlight, dampness or any heat, Like a hot cup of coffee or tea. Always use a coaster.
 Excessive exposure to sunlight may cause fading.
 Excessive temperature and humidity or cold may cause cracking or splitting.
 Dust with a clean, damp, lint free cloth.
 Use a damp cloth with water or mild detergent to clean all surfaces. Do not use chemicals or paint thinner which will fade the surface.
 Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.