

Thank You for purchasing this Quality product. It has been engineered for easy assembly yet constructed for durability. Please take the time to read and follow the instruction while assembling.

ASSEMBLY INSTRUCTION

38" ARROW BACK WINDSOR CHAIR

18"(W) x 20" (D) x 38¹/₂"(H)

Model : DLU-820-RTA (C-0623-RTA)



List of hardware For 1 Chair

Omenan	JCBC Bolt M6 x 45mm	2
Oran	JCBC Bolt M6 x 30mm	6
0	Spring Washer 14"	6
0	Flat Washer ¹ / ₄ " x 13mm	6
CB	JRN Nut	2
	Allen Key M4	1
Ø	Wood Button	2
	0 	Image: Spring Washer 1/14" Image: Spring Washer 1/14"

Important Notes

- Keep all hardware parts out of reach of children.
- Must tighten screws periodically.With use screws will become loose.Check tightness of all screws every 6-8 weeks.
- * Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- immediatedly.
 * Do not tighten all screw / bolt until all completely assembled.

Notes

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials
 including staples & packing straps
 before you start to assemble.
- Do not tighten all screws / bolts until all completely assembled.
 Care And Maintenance
- * The Touch of a soft cloth is all the maintenance your wood pieces will ever need.
- ★ Never use harsh chemicals or abrasive cleaner as they could mark or destroy finish.

