

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.

Remove wooden furniture from standing water. Dust regularly with small brush or vacuum



Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening



Part List and Hardware List

| PIECE | DESCRIPTION | PICTURE | QUANTITY |
|-------|-------------|--|----------|
| A | Seat Frame |  | 2X |
| B | Leg Frame |  | 1X |
| C | Back frame |  | 1X |
| D | Screw -1 |  6x80mm | 2X |
| E | Screw -1 |  6x60mm | 8X |
| H | Allen key |  | 1X |

Model# PAT7007

Product Dimensions:46.85" W x 26.38" D x 32.48" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key


1



Step 1

Attach leg frame (A) to back frame (C), use screws-1 (D), tighten with allen key(H1). Use screw -1 (E) to connect leg frame (A) with seat frame (B), tighten with allen key (H1).

2



Step 2

Tighten screw- 1 (E) with allen key (H1) to attach seat frame (B) and back frame (C)

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.

Remove wooden furniture from standing water. Dust regularly with small brush or vacuum


Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening



Part List and Hardware List

| PIECE | DESCRIPTION | PICTURE | QUANTITY |
|-------|-------------|--|----------|
| A | Leg Frame |  | 2X |
| B | Seat Frame |  | 1X |
| C | Back frame |  | 1X |
| D | Screw -1 |  6x80mm | 2X |
| E | Screw -1 |  6x60mm | 6X |
| H | Allen key |  | 2X |

Model# PAT7007

Product Dimensions: 23.23" W x 26.38" D x 32.48" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key


1



Step 1

Attach leg frame (A) to back frame (C) ,use screws-1 (D),tighten with allen key(H1).Use screw -1 (E) to connect leg frame (A) with seat frame (B), tighten with allen key (H1).

2



Step 2

Tighten screw- 1 (E) with allen key (H1) to attach back frame(C)

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.

Remove wooden furniture from standing water. Dust regularly with small brush or vacuum

Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.



NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List

| PIECE | DESCRIPTION | PICTURE | QUANTITY |
|-------|-------------|--|----------|
| A | Leg frame |  | 2X |
| B | Top table |  | 1X |
| C | Cross bar |  | 2X |
| D | Cross bar |  | 1X |
| E | Screw |  6x60mm | 12X |
| H | Allen key |  | 1X |

Model# PAT7007

Product Dimensions:40.15" W x 19.68" D x 16.93" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key


1



2



3



Step 1

Attach Leg frame (A) to (C),(D),use allen key (H) to tighten screws (E).

Step 2

Attach (A),(C),(D) to (B), use allen key (H) to tighten screws(E).

Step 3

Complete.