

SKU #15212


Beginning:

! Unpack all parts and hardware to ensure you have all needed components for assembly.
! Read this guide cover to cover before the assembly.
! Assemble this item on a soft surface, such as carpet to protect finish.
! Proper assembly of this item requires 2 people & 10 minutes to assemble.

CARE INSTRUCTIONS

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners. Any liquid spilled on the product should be cleaned up immediately with a damp cloth.


Parts





HOW TO ASSEMBLE

STEP-1 Place the Desk Top upside down on rug.
STEP-2 Match Marking of A with A&B,C,D respectively
STEP-3 Insert allen bolt (E) with washer (G&F) & tighten with Allen key.(H)
STEP-4 Turn The Desk upside Down. Desk is Ready to use.

Hardware & Tools required:



(E) Allen Bolt 4 + 1 Extra 0.3" X 2" 

(F) Lock Washer 4 + 1 Extra 0.39" 



(G) Washer 4 + 1 Extra 0.39" 

(H) Allen Key 1 0.2" 


STEP-1



STEP-2



STEP-3



STEP-4