
For Style 1154P43 Assembly Instruction Sheet #IS-1154P43


• Required: Fairlead acrewdriver, Philips acrewdriver, pilers, who cutters, who attippers, electrical taps, eatilety glasses.
• Source: (12) G8 40W Maximum (loci Include).
• Research (12) G9 40W Maximum (loci Include).
• Research (12) Fairle (10-20 minutes
• R

Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the ficture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal





A. Fit the ceiling canopy to Mounting Screws (DD) and secure with Mounting Bells (AA). Note: The ceiling canopy should be snug against the ceiling and the Mounting Bells (AA). If not, edjust the length of the then screwing Mounting Screws (DD) in or out of the Crossbar (EE) until the xorrect length is achieved. nd Lock Washer and **bunting Screws (DD) by** ing the Hex Nut




Figure 3