

## ASSEMBLING & INSTALLATION INSTRUCTIONS

The drawing shown may not exactly match the product enclosed. However, the installation instructions do apply to this product.

## 20584 20585

- WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.
- ♦ ATTENTION! COUPER LE COURANT AU FUSIBLE OU UN DISJONCTEUR.

## ASSEMBLING THE FIXTURE (Fig.1)


- 1. Shut off the power at the circuit breaker and remove old fixture, including the single bar. Carefully unpack your new fixture and lay out all the parts on a clear area. Take care not to lose any small parts necessary for installation.
- 2. Attach the mounting screw part way into the side hole of the crook cross bar, then lock it securely with hex nut. Attach the cross bar to the junction box using two box screws as shown. The side of the cross bar marked "GND" must face out. The junction box is not included.
- 3. Follow wiring instructions carefully (see fig.2).
- 4. Attach the back plate of lamp body onto the junction box, aligning screws on cross bar with mounting holes and lock it securely with the ball nuts. Raise the candle sleeve insert to the lamp holder.
- 5. Install the light bulbs(Not included) in accordance with the fixture's specifications. NOTE: DO NOT EXCEED THE MAXIMUM WATTAGE RATING!
- 6. With silicone caulking compound, caulk completely around where back of cover meets with the wall surface to prevent water from seeping into junction box.

## CONNECTING THE WIRES (Fig.2)

- 1. Connect the electrical wires as follows. Connect the Black wire from the fixture to the black house (hot) Wire. Connect the white wire from the fixture to the white (neutral) house wire. Make sure all wire nuts are secured. You may wrap the connections with electrical tape. If your outlet box has a ground wires (green or bare copper) connect fixture's ground wire to it. Otherwise attach the bare copper fixture wire to the green ground screw on the crossbar.
- 2. Tuck the wire connections neatly into the wall junction box.

Your installation is now complete. Return power to the junction box and test the fixture.

FIG.1



©COPYRIGHT ALL RIGHTS RESERVED. LIVEX LIGHTING.INC.