



Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.





Pre-assembly:

- Do not discard any content until assembly completed to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description		QTY
P1	Bench		1
P2	Legs		4

Hardware List


Item	Description		QTY
H1	Bolts φ1/4*2-3/8."		8
H2	Lock Washers φ1/4"		8
H3	Flat Washers φ1/4"		8
H4	Allen Wrench φ1/4"		1

DISCLAIMER:


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Assembly Procedures:


Step 1. Assemble the bench on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Remove legs and hardware from bench.



Step 2. Assemble the bench on a flat, soft surface such as carpet or cloth to prevent scratching. Using bolts (H1), lock washers (H2), flat washers (H3), and Allen wrench (H4). Tighten bolts (H1) with allen wrench (H4).



Step 3. Place bench upright on a level surface. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY:

BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.

Thank you for your purchase