ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver & Hammer (not provider).

PART LIST		
ITEM	DESCRIPTION	QTY
Α	HEADBOARD TOP	1 PC
В	HEADBOARD WIND	2 PCS
С	FOOTBOARD	1 PC
D	SIDE RAIL (L&R)	2 PCS
E	CENTER RAIL	1 PC
F	CENTER SUPPORT LEG	3 PCS
G	CENTER SUPPORT	2 PCS
Н	BED LEG	4 PCS
I	BED SLAT	26 PCS

HARDWARE LIST			
ITEM	DESCRIPTION		
1	WOOD DOWEL M8 X 30mm	4 PCS	
2	JCBB BOLT M6 x 20mm	8 PCS	
3	JCBB BOLT M6 x 40mm	10 PCS	
4	M6 FLAT WASHER	18 PCS	
5	M6 SPRING WASHER	8 PCS	
6	JCBC BOLT M8 x 40mm	10 PC	
7	M8 FLAT WASHER	10 PCS	
8	M8 SPRING WASHER	10 PCS	
9	WOOD SCREW M3.5 x 16mm	8 PCS	
10	WOOD SCREW M4 x 20mm	2 PCS	
11	BED SLAT SIDE FITTER	26 PCS	
12	BED SLAT CENTER FITTER	13 PCS	
13	M4 ALLEN KEY (BALL SHAPE)	1 PC	
14	M5 ALLEN KEY (BALL SHAPE)	1 PC	







