

JONATHAN ADLER

FURNITURE

Harlequin Chest


Assembly Instructions

- For ease of assembly TWO people are recommended.

Parts Included:

Box 1:

- (1pc) Console Top-A







Box 2:

- (4pcs) Leg - B



Hardware Enclosed :

C	 Bolt	12pcs
D	 Spring Washer	12pcs
E	 Flat Washer	12pcs
F	 Allen Wrench	1pc

Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product.

Necessary Persons:




Please check the package contents before assembly. A full checklist of components is given in this diagram. If any components are missing, please contact Jonathan Adler Client Services.


The hardware pack contains **small pieces** which should be **kept away from children**.

Assembly Instructions:


1. Remove all the components from their boxes and place them on a carpeted or scratch-free surface.
2. Place the Console Top (A) backside down. Align the predrilled holes of the Legs (B) to the Top; secure with Bolts (C), Spring Washers (D) and Flat Washers (E) by using the Allen Wrench (F).



3. Stand the chest upright and adjust the levelers under the legs if needed.



4. Assembly is completed.



Ensure all bolts are fully tightened every three months to ensure stability.