



## 58" Dancing Mrs. Claus with Basket



Who's helping Santa and dancing along the way? Mrs. Claus, that's who! Our dancing Mrs. Claus from Fraser Hill Farm will dance right into your heart as she helps you greet your family, guests or customers. Standing 58 inches tall and holding a basket filled with holiday greenery, she will be a delightful addition to your holiday decor in any home, office or store.

When motion is detected, she will move her arms and sway her body to the music. Dressed in a tartan plaid skirt and coordinating mob-cap, her friendly face and warm smile will fill you and yours with holiday cheer!

- 58" motion activated Mrs. Claus
- Dances when motion is detected
- Warm smile with silky straight hair and spectacles
- Dressed in a red velvet jacket and plaid skirt
- "Ding Dong Merrily on High" plays while she moves
- 6-ft. power cord uses standard 115V electrical outlet

Model Number	UPC	Dimensions	Description
FAMC058M-13RED	192487081099	21.3" x 15" x 58"	Dancing Mrs. Claus with Basket