


















ASSEMBLY INSRTRUCTION

WF 304266AAD&WF 304266AAK














			
① x 1	② x 1	③ x 1	④ x 1
			
⑤ x 1	⑥ x 1	⑦ x 1	⑧ x 2
			
⑨ x 1			

			 Φ3x14mm	
A x20+2	B x22+2	C x22+2	D x15+2	E x3
				
F x1	G x1	H x1	I x12+1	J x12+1
	 Φ4x12mm	 Φ4x35mm		
K x1	L x1	M x1	N x1	


step 1



step 2




step 3




C x1

step 4




C x3

step 5




C x3

step 6






C x3





step 7





step 8






step 9



step 10



step 11



step 12

