ASSEMBLY INSTRUCTIONS

Description: Willshire Settee

Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Des	QTY		
P1	Settee Seat		1	
P2	Back Left Leg		1	
P3	Back Right Leg	N B	1	
P4	Front Left Leg with Arm		1	
P5	Front Right Leg with Arm	P3	1	
P6	Settee Back		1	

Hardware List

Item	Description		QTY
H1	Long Bolts	0	8
H2	Short Bolts Ø1/4"*1-3/4"L	0	6
H3	Lock Washers 1/4"	Q	14
H4	Big Flat Washers 1/4"	0	8
H5	Small Flat Washers 1/4"	0	6
H6	Allen Wrench 1/4"		1
H7	Wooden Plugs	Ø	4

DISCLAIMER:

WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.



Assembly Procedures:

Step 1. Assemble the settee on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Loosely attach the back left leg (P2) and the back right leg (P3) to the bottom of settee seat (P1) as shown below image 1.



Step 2. Loosely attach the front left leg with arm (P4) and the front right leg with arm (P5) to the settee seat (P1), the back left leg (P2) and the back right leg (P3) as shown below image 2.





Step 4.

- 1) Make sure the settee is level and securely tighten all bolts by Allen wrench (H6).
- 2) Attach the wooden plugs (H7) to each exposed bolt holes, tighten with rubber hammer to knock the wooden plugs till its tighten. **Note:** use a soft cloth between the wooden plug and hammer to prevent damage to the wooden plug finish.
- 3) Assembly is complete. Failure to follow these instructions may cause the bolts to misalign during assembly.

(H7)x4 Wooden Plugs ()



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY. Thank you for your purchase