Responsible Lighting®

SAFETY INSTRUCTION

WARNING – To reduce the risk of FIRE, ELECTRIC SHOCK, EXPOSURE TO EXCESSIVE UV RADIATION, and OR INJURY TO PERSONS:

- Turn off/unplug and allow cooling before replacing bulb (lamp).
- Bulb (lamp) gets HOT quickly! Only contact switch/plug when turning on.
- Do not touch hot lens, or guard.
- Do not remain in light if skin feels warm.
- Do not look directly at lighted lamp.
- Keep lamp away from materials that may burn.
- Use only with a 50-watt or smaller bulb (lamp).
- Do not touch the bulb (lamp) at any time. Use a soft cloth. Oil from skin may damage bulb (lamp).
- Do not operate the luminaire with a missing guard.

SAVE THESE INSTRUCTIONS

INSTALLING LAMP:

- 1. Use a 12V MR16 lamp 50watt maximum (purchase separately).
- 2. Align lamp pins with socket holes and gently press in.
- 3. Place Clear glass lens over lamp and secure with retaining ring.

INSTALLING CLAMP:

- 1. Installs on a firm flat surface, such as wood, particleboard, cubicle partition etc. Standard clamp accommodates surfaces 1/2" to 2 1/2" wide.
- 2. Use the angle adjustment knob on the side to change the angle.
- 3. Adjust the height by sliding the telescoping rod.

ACCESSORIES:

- 1. Supplied with standard clamp that opens to 2 1/2' wide.
- 2 An optional "DLC-4" clamp opens to 4".
- 3. An optional DLC-P clamp works on 2 1/2" pipe
- Fixture supplied with clear glass lens. Maybe substituted with various accessory lenses consult catalog for compatibility.