




Assembly Instruction Sullivan Media Console




Page 1 of 10

Part list







2 Lower Middle Panel




(3) Left Side Panel



x 1






(4) Right Side Panel


(5) Upper Middle Panel




6 Fixed Panel




7 Top Panel




(8) Upper Back Panel



(9) Lower Back Panel



10 Door



11 Leg




12 Support Leg



x 4




13 Adjustable Shelf Panel



Page 2 of 10

Hardware list

- A Cam Bolt
- Cam Lock
- Wood Dowel
- (D) Plastic Cover







x 20

x 20

x 18


x 16

Bolt

Screw

Shelf Holder

(H) Washer



x 4



x 33



x 8



x 4



(BB) Plastic Anchor

(CC) Plastic Chain

Screw For Bracket



x 4






x 2





x 4


Screw For Wall


x 4














Page 9 of 10

