

NOTE:

This brochure contains IMPORTANT safty info. Please read and keep for future reference.

MAINTAINANCE AND WARNING

- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, For residential use only.





PARTS



PARTS



PARTS



HARDWARE LIST

	2 x1	3 x1
Bolt ø1/4"x1-3/4"L	Allen wrench	Magnet
4 x28	5 x12	6 x8
Screw ø3x15mm	Shelf holder	Knob
7 x8 bolt	8 x24 Screw	9 x4
ø4x19mm	ø8x25mm	Hinge
10 x4 Hinge	11 x52 Screw ø3x15mm	12 x4 Bracket
13 x4 Image: state sta	14 x4 Some Screw Ø7x35mm	15 x2 Tie
screwdriver		7/35





Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.



Attach leg(X/Y) to bottom panel(B) with bolt(1), tight it with Allen wrench(2).



Attach Magnet(3) to front rail (C) with screw(4) , tight it with screwdriver(16).

Step 3



Slide front rail(C) to middle left vertical panel(E) and middle right vertical panel(F).



Attach left side panel(D) and right side panel(G) to preassemble unit at step 3, and tight it with Allen wrench(2).



Attach preassemble unit at step 4 to bottom panel(B) , and tight it with Allen wrench(2).



Attach preassemble unit at step 5 to top panel(A), and tight it with Allen wrench(2).



Attach back panel(H) to preassemble unit at step 6 with screw (4), tight screw with screwdriver(16).



Insert shelf holder (5) to preassemble unit at step 7 , and attach adjustable shelf (I/J) to it.





Attach drawer side right(O) and drawer side left(N) to drawer front left (K) with screw(8), tight it with screwdriver(16), slide drawer bottom side (R) to them. Attach konb(6) to drawer front left(K) with bolt(7). Tight bolt with screwdriver(16).

Step 10



Attach drawer back side(P) to preassemble unit at step 9 with screw(8), tight screw with screwdriver(16).



Attach drawer side right(O) and drawer side left(N) to drawer front right (M) with screw(8), tight it with screwdriver(16), slide drawer bottom side (R) to them. Attach konb(6) to drawer front right(M) with bolt(7). Tight bolt with screwdriver(16).

Step 12



Attach drawer back side(P) to preassemble unit at step 11 with screw(8), tight screw with screwdriver(16).





Attach drawer side right(O) and drawer side left(N) to drawer front middle (L) with screw(8), tight it with screwdriver(16), slide drawer bottom middle (S) to them. Attach konb(6) to drawer front middle(L) with bolt(7). Tight bolt with screwdriver(16).





Attach drawer back middle(Q)to preassemble unit at step 13 with screw(8), tight screw with screwdriver(16).



Make sure to move the ball bearing to front end, carefully align male and female slides before insert drawer box.

Attach drawer to preassemble unit at step 15.

Step 16

Once the drawer is assembled, if the drawer face does not fit the wood frame, perform the following operations:





Attach hinge(9) to left door(T) with screw (11). Tight screw with screwdriver(16), attach knob(6) to left door(T) with bolt (7), tight bolt with screwdriver(16)



Attach hinge(9) to right door(W) with screw (11). Tight screw with screwdriver(16), attach knob(6) to right door(W) with bolt (7), tight bolt with screwdriver(16)



Attach hinge(10) to middle left door(U) with screw (11). Tight screw with screwdriver(16), attach knob(6) to middle left door(U) with bolt (7), tight bolt with screwdriver(16)



Attach hinge(10) to middle right door(V) with screw (11). Tight screw with screwdriver(16), attach knob(6) to middle right door(V) with bolt (7), tight bolt with screwdriver(16)



Attach left door(T) and right door(W) to preassemble unit at step 15 with screw(11) , tight screw with screwdriver(16).



IX. Concealed hinges are three-way adjustable.



Horizontal by screw adjustment

Doot Side panels

by loosening the hinge-arm mounting screw or via cam adjustment



Vertical Via slots in the mounting plate or via cam adjustment

Close the door , if the doors are not at the desired position , please adjust it as shown.



Attach middle left door(U) and middle right door(V) to preassemble unit at step 21 with screw(11), tight screw with screwdriver(16).





Horizontal by screw adjustment



In-and-Out by loosening the hinge-arm mounting screw or via cam adjustment



Vertical Via slots in the mounting plate or via cam adjustment

Close the door , if the doors are not at the desired position , please adjust it as shown.



Attach bracket(12) to preassemble unit at step 24 with screw(11), and tight screw with screwdriver(16).



Drill hole on the wall, and insert expansion nut(13), then attach bracket(12) to it with screw(14), tight screw with screwdriver(16).



Attach the unit to the wall with plastic belt (15)

Anti-tipping hardware must be used for this product to avoid tipping and injury.

If the unit is not stable , please adjust the adjustable level.

WARRANTY

We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having difficulty with assembly? Missing parts? Please send email with your order No to <u>customerservice@hulalahome.com</u> For return, please check the return policy with the retailer or market place you bought from.

Appreciate your purchasing from us. Pop up your life by our furniture piece!