



ASSEMBLY INSTRUCTION



Sunpan Item No: **106742**

Sunpan Product Name: **ALTMAN NIGHTSTAND**

Please visit our website www.sunpan.com for more great products.

For assembly questions please call **1-800-787-1019 (or +1-416-736-0094)** outside North America or email to infor@sunpan.com

PARTS LIST

Before you begin, please layout all parts and ensure you have the correct count.

NO.	DESCRIPTION	QUANTITY	ILLUSTRATION
A	Nightstand	1	
B	Set of Tipping Restraint	2	

FURNITURE TIPPING RESTRAINT INSTRUCTION

STEP	DESCRIPTION	ILLUSTRATION
1	Attach two of the mounting brackets near the top back edge of the furniture by inserting the shorter screws.	

FURNITURE TIPPING RESTRAINT INSTRUCTION

STEP	DESCRIPTION	ILLUSTRATION
2	<p>Determine the final position of the dresser. Mark locations on the wall approximately 2" below the brackets mounted to the back of the furniture.</p> <p>Drill a shorter hole into the wall stud. If wall stud is not available, drill a hole into the wall and insert plastic anchor. Gently tap the anchor until the flange is flush with the wall.</p> <p>Attach the second set of brackets by inserting the longer screw through the bracket and into the wall.</p> <p>Place the furniture so that the brackets on the back edge are in line with the brackets in the wall.</p> <p>Lace one end of the nylon restraint strap down through each bracket. Bring both ends together and slide the beaded end until it snap locks into the keyhole slot.</p> <p>To double lock; return the beaded end back through the keyholes as shown.</p> <p>Check to make sure the straps are securely laced and locked to the brackets.</p> <p>Repeat all above step to attach other tip-kit position.</p>	

ASSEMBLY TIPS:

Please check parts and hardware before assembling. Follow each instruction step by step.

Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.

Remove all parts from the carton and separate them into part numbers / groups as indicated on the part list.

Please follow instructions in the sequence as numbered to assure fast / easy assembly.

WARNING:

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement.

Keep all hardware parts out of the reach of children.

FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time.

Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.

Excessive exposure to sunlight may cause fading.

Excessive temperature and humidity or cold may cause cracking or splitting.

Dust with a clean, damp, lint free cloth.

Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.

Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.