


PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS

ITEM NO. / ARTICLE NO. / ARTICULO NO: P349100

DESCRIPTION/LA DESCRIPCION/DESCRIPCIÓN : 8 Drawer Dresser-Commode à tiroirs-Tocador con cajones

AWARNING



- NEVER put a TV on this product
 NEVER allow children to stand, climb or hang on drawers,
- doors, or shelves.

 NEVER open more than one
- drawer at a time.

 Place heaviest items in the lowest drawers.

 This is a permanent label.



- x1 Support leg *
- x1 Pattes centrales
- x1 Patas centrales



- (H)
- x3 Front Legs *
- x3 jambes
- x3 Piernas





- x2 Back Legs *
- x2 jambes
- x2 Piernas





- x3 Bolt 5/16*80mm *
- x3 Boulon
- x3 Perno






- x3 Lock washer 5/16mm *
- x3 Rondelle de blocage
- x3 Arandela de Seguridad







- x3 Flat Washer 5/16*16mm *
- x3 Rondelle plate
- x3 Arandela plana



- x1 Allen Wrench 73*29*5mm *
- x1 Clé hexagonale
- x1 Llave Allen



- x1 Tipping restraint *
 x1 Liste des pièces de
 quincaillerie antibasculement
- x1 Abrazadera antivuelco

RC-FG-WHITE

- x4 Adjustable leveler-White *
- x4 Patin réglable
- x4 Nivelador ajustable

* Replaceable Part




ASSEMBLY INSTRUCTIONS/ NOTICE DE MONTAGE/ INSTRUCCIONES DE MONTAJE

ITEM NO. / ARTICLE NO. / ARTICULO NO: P349100

DESCRIPTION/LA DESCRIPCION/DESCRIPCIÓN :8 Drawer Dresser-Commode à tiroirs-Tocador con cajones

AWARNING Children have died from furniture tipover. To reduce the risk of furniture tipover: ALWAYS install tipover restraint provided. NEVER put a TV on this product. NEVER allow children to stand, climb or hang on drawers, doors, or shelves. NEVER open more than one drawer at a time. Place heaviest items in the lowest drawers. This is a permanent label. Do not remove!





REPLACEABLE PART/ PARTIE REMPLACABLE/ PARTE REEMPLAZABLE

ITEM NO. / ARTICLE NO. / ARTICULO NO: P349100

DESCRIPTION/LA DESCRIPCION/DESCRIPCIÓN 8 Drawer Dresser-Commode à tiroirs-Tocador con cajones



WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover: • ALWAYS install tipover restraint

- provided.

 NEVER put a TV on this product
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest tems in the lowest drawers.
- This is a permanent label.

 Do not remove!



RP349100-CELEG *

- x1 Support leg
- x1 Pattes centrales
- x1 Patas centrales



RP349100-FLEG *

- x3 Front Legs
- x3 jambes
- x3 Piernas



RP349100-BLEG *

- x2 Back Legs
- x2 jambes
- x2 Piernas



RC-FG-WHITE *

- x4 Adjustable leveler-WHITE
- x4 Patin réglable
- x4 Nivelador ajustable




- ^PRP349100-HWKIT *
- x1 Hardware Kit
- x1 Liste des pièces de quincaillerie
- x1 Lista del materiales



RC-WH-NAIL *


- x2 Plastic Nail
- x2 Clou en plastique
- x2 Clavo de plástico



RP349100-KNOB *

- x16 Knob with screw
- x16 Tirer et vis
- x16 Tire y Tornillo





COMGLIDE-10-45 *

- x8 Full Extension guides 10"L x 45mmW
- x8 Rails à extension complète

RC-ANTI-TIP *

x1 Tipping restraint

x1 Liste des pièces de

x1 Abrazadera antivuelco

quincaillerie antibasculement

x8 Rieles completamente extensibles



RP349100-LFELT *

- x1 Removable Felt-Left&Black
- x1 Feutre
- x1 Fieltro



RP349100-RFELT *

- x1 Removable Felt-Right&Black
- x1 Feutre
- x1 Fieltro

* Replaceable Part

Protect Your Wood or Laminate Flooring

*This statement applies to any floor without carpet.

If not careful, all furniture including upholstery and case pieces can scratch, scuff and even gouge floors. The recommendation is to have felt, rubber pads or area rugs under furniture on flooring without carpet.

Moving your furniture

Pushing and dragging furniture over floors without carpet can lead to scratches and scuffs. Have someone help when moving the larger pieces of furniture by lifting, try using a dolly or moving pads.

Felt and rubber pads

Applying furniture pads to the feet of furniture helps cushion contact points. Furniture pads can be found at local hardware stores. Felt pads slide easily across the floor, making them ideal for dining chairs and other pieces that move with use. Rubber pads will help furniture stay in place and are perfect for larger pieces, like sofas and loveseats.

Area rugs and rug pads

Using an area rug under furniture is another way to protect your floor from scratches and scuff marks. A rug pad under the area rug will provide extra cushion and added protection.