



# Riverby®

## Top-mount Kitchen Sink

### K-5872-1A1

#### Features

- 27-inch minimum base cabinet width.
- Single bowl.
- 9" depth provides generous workspace.
- Single faucet hole.
- Bowl slopes 2 degrees toward drain to minimize water pooling.
- Offset drain increases workspace in the sink and storage space underneath.
- Includes stainless steel sink rack.
- Small size fits compact spaces.

#### Material

- KOHLER® enameled cast iron.

#### Installation

- Top-mount.

#### Recommended Products/Accessories

K-6238 Sink Rack  
K-8801 Sink Strainer  
K-8799 Sink Strainer  
K-23726 Drain treatment  
K-23725 Cast iron cleaner

#### Optional Products/Accessories

K-6194 Utility Rack With Soaking Cup  
K-6239 Colander with Cutting Board  
K-6246 Cutting Board  
1054375 Undermount sink kit, 23"  
K-11352 Disposal Flange with Stopper  
K-9000 P-Trap

#### Included Components

Product consists of:  
K-6238 Sink Rack



#### Codes/Standards











ASME A112.19.1/CSA B45.2



#### KOHLER® Enameled Cast Iron Kitchen Sink Lifetime Limited Warranty

See website for detailed warranty information.

#### Available Colors/Finishes

*Color tiles intended for reference only.*

Color	Code	Description
	0	White
	FF	Sea Salt™
	96	Biscuit
	47	Almond
	FD	Cane Sugar™
	95	Ice™ Grey
	G9	Sandbar
	K4	Cashmere
	KA	Black 'n Tan
	7	Black Black™



## Technical Information

All product dimensions are nominal.

Bowl configuration: Single

Installation: Top-mount

Min. base cabinet width: 25" (635 mm)

Bowl area (Only): Length: 22-1/4" (565 mm)  
Width: 15-13/16" (402 mm)  
Bowl depth: 9" (229 mm)

Number of deck holes: 1

Faucet hole(s): 1-3/8" (35 mm)

Drain hole: 3-7/8" (98 mm)

Template: 1172565-7, required, included

## Notes

Install this product according to the installation instructions.

**NOTICE:** Countertop manufacturer or cutter must use the cut-out template provided with the product, or a current one provided by Kohler Co. (call 1-800-4-KOHLER). Kohler Co. is not responsible for cutout errors when the incorrect cut-out template is used.

**IMPORTANT!** Use of the colander, wood cutting board, and utility rack requires the "reveal" cutout option on the cutout template.