
Keep your Rocking Chair cover clean with these simple spot cleaning instructions.



Blot Dry

When spills occur: using a gentle touch, carefully blot up any spills with a towel. Do not rub frantically, as this will drive the stain further into the weave of the fabric, making it even more difficult to remove. If the spilled substance is a thick product, i.e. mud, let it dry before prying off and brushing away any residue.

Spot Clean

Most stains can be spot-cleaned with just a touch of mild soap and water. Most spills will bead on the surface and can be absorbed with a paper towel before leaving a residual stain. If a stain does occur, remove the cover and put it in the washing machine.



If the stain remains, clean with these simple washing instructions.



Remove Cover

Unsnap and remove cusion from rocking chair. Unzip and separate the outer cover from the interior foam of the chair. Cover should only be removed by an adult. Keep foam and cover away from children while they are separated.

Machine Wash Cold

Wash outer cover ONLY on the gentle/delicate cycle in cold water. Wash with like colors. Fabric dyes may bleed. Do not use a bleach solution. DO NOT WASH FOAM.

Tumble Dry Low

Dry outer cover on the tumble/air cycle. Put cover back on the foam when it is completely dry and cool. Zip up and snap back into place on your rocking chair.