



HOOKER  
— FURNITURE —

# ASSEMBLY INSTRUCTION

Item: 5382-55494

Scaffold Entertainment-Bookcase

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:

HARDWARE PACK

NO	DRAWING	DESCRIPTION	SIDE	Q' TY
A		BOLT	Ø1/4" * 1-5/8"	40pcs
B		BOLT	Ø1/4" * 7/8"	21pcs
C		FLAT WASHER	Ø1/4" * 16mm	61pcs
D		ALLEN WRENCH	4mm	1pc
E		ANTI-TIP HARDWARE		1pc

