
INSTRUCTIONS FOR MODELS

S-2764-E2 S-2764-E175



NEED HELP?

For additional assistance or service please contact:

SPEAKMAN®



فَرِينَ 800-53*7-*2107



customerservice@speakman.com



www.speakman.com

92-S-2764-02

TOOLS AND SUPPLIES

Thread Seal Tape (INCLUDED)

Adjustable Wrench





\triangle

IMPORTANT



Be sure to read instructions thoroughly before beginning installation. Do not overtighten any connections or damage may occur.

NOTE: Rain shower heads are intended to be used with a vertical drop shower arm. If used at an angle, the shower head will not produce the correct flow rate for the product.

SAFETY TIPS



Cover your drain to prevent loss of parts.

MAINTENANCE



Periodic cleaning using a mild soap and warm water will help keep your Shower Head's appearance in its original condition.


For best results, dry immediately with a soft, clean cloth. DO NOT USE harsh and/or abrasive cleaners.


In certain water conditions, mineral deposits may form. To remove these deposits, it is recommended that you soak the shower head in a solution of 2 parts vinegar to 1 part water for one hour. Rinse thoroughly with fresh water. Brush off any remaining mineral deposits from the spray channels.

WARRANTY




Warranty information can be found at: www.speakman.com









Max. Flow Rate: 2.0 gpm (7.6 L/min)

Min. Flow Rate: 1.75 gpm (6.6 L/min) @ 45psi FOR USE WITH AUTOMATIC COMPENSATING VALVES RATED AT 6.6 L/MIN (1.75 GPM) OR LESS.

DIMENSIONS SUBJECT TO CHANGE WITHOUT NOTICE.

Max. Flow Rate: 1.75 gpm (6.6 L/min) Min. Flow Rate: 1.5 gpm (5.7 L/min) @ 45psi FOR USE WITH AUTOMATIC COMPENSATING VALVES RATED AT 5.7 L/MIN (1.50 GPM) OR LESS.