



ASSEMBLY INSTRUCTIONS

Description: Fatima Accent Table

Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:


- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description	QTY
P1	Table Top	1
P2	Mounting Plate	1
P3	Center Post	1
P4	Legs	4
P5	Bottom Frame	1

Hardware List

Item	Description	QTY
H1	Long Bolts $\phi 1/4'' \times 1-1/2''$ L	2
H2	Short Bolts $\phi 1/4'' \times 1-1/4''$ L	12
H3	Lock Washers 1/4"	14
H4	Flat Washers 1/4"	14
H5	Allen Wrench 1/4"	1



DISCLAIMER:


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Assembly Procedures:

Step 1. Assemble the table on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach the mounting plate (P2) to the legs (P4) and the center post (P3) as shown below image 1.

- (H1)x1 Long Bolts $\phi 1/4'' \times 1-1/2''$ L
- (H2)x4 Short Bolts $\phi 1/4'' \times 1-1/4''$ L
- (H3)x5 Lock Washers 1/4"
- (H4)x5 Flat Washers 1/4"
- (H5)x1 Allen Wrench 1/4"

Note: Make sure the radius edge side of leg is not located on the bottom.



Step 2. Attach the bottom frame (P5) to the legs (P4) and the center post (P3) as shown below image 2.

- (H1)x1 Long Bolts $\phi 1/4'' \times 1-1/2''$ 
- (H2)x4 Short Bolts $\phi 1/4'' \times 1-1/4''$ 
- (H3)x5 Lock Washers 1/4" 
- (H4)x5 Flat Washers 1/4" 
- (H5)x1 Allen Wrench 1/4" 





Image2

Step 3.

- a. Attach the assembled mounting plate (P2) to the table top (P1) as shown below image 3.
- b. Securely tighten all bolts with Allen wrench (H5). Turn the assembled table to an upright position.
- c. To level table. If there is a gap between a leg and the floor, please adjust the adjustable leveler up or down under each leg. See image 3.
- d. Assembly is complete. Failure to follow these instructions may cause the bolts to misalign during assembly.

- (H2)x4 Short Bolts $\phi 1/4'' \times 1-1/4''$ 
- (H3)x4 Lock Washers 1/4" 
- (H4)x4 Flat Washers 1/4" 
- (H5)x1 Allen Wrench 1/4" 

Image 3



ADDITIONAL NOTE ABOUT SAFETY:

BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE.

THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.

Thank you for your purchase