

ASSEMBLY INSTRUCTION

SUNPAN







Sunpan Product Name: **JAMILLE DESK**



Please visit our website www.sunpan.com for more great products

For assembly questions please call **1-800-787-1019 (or +1-416-736-0094)** outside North America or email to info@sunpan.com

PARTS LIST

Before you begin, please layout all parts and ensure you have the correct count.

| PARTS | DESCRIPTION | QUANTITY | ILLUSTRATION |
|-------|-----------------|----------|---|
| A | Top | 1 |  |
| B | Base Left | 1 |  |
| C | Base Right | 1 |  |
| D | Washers | 12 |  |
| E | Bolts (Ø6*20mm) | 12 |  |
| F | Allen Key | 1 |  |

| ASSEMBLY INSTRUCTIONS | | |
|-----------------------|---|---|
| STEPS | DESCRIPTION | ILLUSTRATION |
| 1 | Place the Bases (B & C) onto bottom of the Top (A). Tighten the Washers (D) and Bolts (E) by using the Allen Key (F). |  |
| 2 | Assembly completed. |  |

ASSEMBLY TIPS:

Please check parts and hardware before assembling. Follow each instruction step by step.

Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.

Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.

Please follow instructions in the sequence as numbered to assure fast/easy assembly.

WARNING:

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement.
Keep all hardware parts out of the reach of children.

FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:

Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.

Excessive exposure to sunlight may cause fading.

Excessive temperature and humidity or cold may cause cracking or splitting.

Dust with a clean, damp, lint free cloth.

Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.

Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.