



HAMPTON'S BUZAAR

www.bazaar.com | customerservice@bazaar.com

Easy Access Fire Pit Spark Screen

Product Information:

The Easy Access Fire Pit Spark Screen comes in four pieces, which when assembled, form a heat-resistant, steel frame screen. Heavy duty steel construction is covered with high-temperature resistant black powder coating for durability. Half of the screen retracts manually on its hinges into the other half of the dome for easy access to tend the fire pit. Handles on either side allow for easy handling and safe operation of the screen.

Please visit our website for Assembly Videos.

Maintenance Suggestions

- All fire pit screens will eventually rust from being exposed to the elements. The rusting process can accelerate in high moisture or humid conditions. For best results, store your screen out of wet or damp conditions, especially in the winter season.
- The heat resistant coating will protect the metal during normal use, but may wear away with time. To maintain and return the screen to its original appearance, any rust may be removed with sandpaper and the surface may be repainted with high-temp gloss black spray paint.
- To prevent the mesh from burning through, prefer not to use any materials that burn at extreme temperatures. DO NOT pile wood to the top of the screen so that the flames come into direct contact with the mesh.

Our Guarantee

All of our products are backed by our 30 days no questions asked return policy. If for any reason you are not satisfied with your purchase, you can initiate a return within 30 days after delivery for a refund, as long as the item is in its original condition and packaging. Please contact us for a Return Authorization (RA) Number if you decide to return your product.

Thank you for choosing Hampton's Bazaar

Our company specializes in manufacturing high quality, stylish and functional fire pit screens. We are committed to providing the best customer service possible.

Over the years, we feel very fortunate to have a large, continuously growing customer base. This would not be possible without the help of our customers who refer us to family and friends. We will keep working very hard to be worthy of your trust.

Please visit our website for information about our products and safety & maintenance tips at www.bazaar.com.



HAMPTON'S BUZAAR

www.buzaar.com | customerservice@buzaar.com



G x 1




D x 8

F x 2


H x 1

Fig. 1 -




A-1, A-2
B-1, B-2

Fig. 2 - Align pre-drilled holes for A-1, A-2



A-1


A-2



C

D

Fig. 3 - Insert screen bolt and nut; securely tighten. Repeat process for B-1 & B-2.



A

B

Fig. 4 - Slide B-assembly into A-assembly.





Fig. 5 - Insert and fasten hinge bolts & nuts.



*Phillips Head Screw/Driver

Fig. 6 Securely tighten hinge bolt and nut.



WARNING! SCREEN WILL BECOME HOT WHEN IN USE! FAILURE TO WEAR PROTECTIVE GLOVES WHEN HANDLING MAY LEAD TO INJURY.

Note: Use small hand wrench to securely tighten acorn nut(s).