ASSEMBLY INSTRUCTIONS 3900093/3900094

Item	Parts	Picture	Qty
1	Chair Body		1
2	Back Legs	P1 P2	2
3	Front Legs		2

Item	Hardware	Picture	Qty
А	Bolt	Ø5/16"X2"	8
В	Spring washer	Ð	8
С	Flat washer	0	8
D	Allen wrench		1

Step 1 : Take out the hardware bag from the bottom of the seat.



Step 2 : Using bolts (A), lock washers (B), flat washers (C) to connect front legs (3) and back legs (P1 and P2) to the bottom of the seat (1). Tighten bolts (A) with allen key (D). Repeat the step for other legs. Turn over the chair and put it on upright position.

