

JENSEN

AIR HOCKEY



Warning

Adult Assembly Required

Asamblea de adultos de advertencia necesaria



MODEL # / No. de Homestead

#26-3565

Assembly and Instructions/Asamblea e Instrucciones

Congratulations!

We hope you will have many hours of enjoyable use with your new Air Hockey Table!



PLEASE KEEP YOUR INSTRUCTIONS!

- Your Model number is necessary should you need to contact us.
- Please read through this instruction book to familiarize yourself with all the parts and assembly steps.
- Refer to the Parts Identifier and verify that all parts have been included.



WARNING!

This is not a child's toy. Adult supervision is required for children playing this game. Please read instructions carefully. Proper use of this set can avoid damage or injury.



BEFORE ASSEMBLY:

- Did you receive 1 box?
- Did you inspect your playfield/main table frame before assembly? It is not replaceable and must be returned to the original place of purchase if damaged.



TOOLS REQUIRED FOR ASSEMBLY:





















- Phillips and Slotted Head Screwdrivers / or Power Driver (not included)
- Allen Wrench (included)

ASSEMBLY INSTRUCTIONS:


We recommend that two adults work together to assemble this table.

- The table will be assembled upside down. This is a very heavy table and turning it right side up will require at least two strong adults.
- We suggest that you use the bottom carton as a clean flat work area to protect the top of your Air Hockey table while assembling.

Parts List


| | | | |
|---|---|---|--|
| <p>#1</p>  <p>Main cabinet 1 piece</p> | <p>#2</p>  <p>Left leg 2 pieces</p> | <p>#3</p>  <p>Right leg 2 pieces</p> | <p>#4</p>  <p>Leg connector 2 pieces</p> |
| <p>#5</p>  <p>Leg panel 2 pieces</p> | <p>#6</p>  <p>1/4"X3/4" Bolt 20 pieces</p> | <p>#7</p>  <p>5/16"X1-1/2" Bolt 20 pieces</p> | <p>#8</p>  <p>5/16" Washer 20 pieces</p> |
| <p>#9</p>  <p>Scorer 1 piece</p> | <p>#10</p>  <p>1/4" Washer 20 pieces</p> | <p>#11</p>  <p>Fixed Seat 2 pieces</p> | <p>#12</p>  <p>Scorer Support 2 pieces</p> |
| <p>#13</p>  <p>Slide Scorer 2 pieces</p> | <p>#14</p>  <p>F4X1" Screw 4 pieces</p> | <p>#15</p>  <p>T3X1/2" Screw 12 pieces</p> | <p>#16</p>  <p>T4X3/4" Screw 4 pieces</p> |
| <p>#17</p>  <p>Leg leveler 4 pieces</p> | <p>#18</p>  <p>Puck 4 pieces</p> | <p>#19</p>  <p>Pusher 4 pieces</p> | <p>#20</p>  <p>Allen Key 1 piece</p> |

Step 1:




- Attach Leg Panel (Part #5) to Left and Right Legs (Parts #2 and #3) using six 1/4" x 3/4" Bolts (#6) and six 1/4" Washers (#10). Finger tighten until all bolts are in place.
- Repeat with remaining legs and panel.

Step 2:



- Attach one leg/panel construction to Main Cabinet (#1), using 5/16" Bolts (#7) and 5/16" Washers (#8).


Step 3:



Attach Leg Connector (#4) to legs as shown, using four 1/4 x 3/4" Bolts (#6) and 1/4" Washers (#10).

Then screw in #17 leg levelers.


Step 4:



Using two strong adults, place the table on its legs.

Attach both Slide Scorers(#13) to table with 1" Screws(#14)


Step 5:



Thread Scorer cord through Scorer Support (#12) as shown. Attach Scorer Support to Scorer(#9) with 3 mm Screw(#15).Repeat on other side

Attach Score Supports to Fixed Seats(#11)with 3mm screws

Step 6:



Attach scoring unit to table,being careful to connect cables as shown.Use four 3/4"Screws(#16)to attach to table