



# ASSEMBLY AND INSTALLATION INSTRUCTIONS

H0188

**WARNING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTES: 1. Before installing, consult local electrical codes for wiring and grounding requirements.  
2. READ AND SAVE THESE INSTRUCTIONS.


## Hardware Package (included):



## Installation Steps

Turn off the power at fuse or circuit box.

1. Thread the long screws through mounting strap, then secure them with two lock nuts. Adjust the length of long screws if necessary.
2. Attach the mounting strap to the outlet box by using two mounting screws.
3. Choose the length of the chains you need and adapt both chains to this length. Connect one end of the chains to the fixture loops by using the loop locks. Then weave the fixture wire and the fixture grounding wire through one of the chains. Then connect the other end of the chains with the canopy loops by using the loop locks.
4. Thread the fixture wires and fixture grounding wire through canopy loops and canopy.
5. Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections using the wire nuts:
  - The smooth wires (marked) from the fixture to the black wire from the power source.
  - The ridged wires (unmarked) from the fixture to the white wire from the power source.
  - Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.
 Carefully put the wires back into the outlet box.
6. Attach the fixture to the mounting strap, and secure it with two ball nuts.



 VAXCEL


171030

7. Attach the glass shades to the glass brackets, then secure them with the socket rings.
8. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
9. Turn on the power at the main fuse or circuit breaker box.

Turn on the power at fuse or circuit box.


The following parts are available for re-order if damaged or missing.

**Spare Parts List:**



→ Mounting Hardware 5768MM

→ Glass Shade 9915CS(3PC)



**A: 38"**  
**B: 11-1/2"**  
**E: 10"**