

Read this instruction carefully. See hardware and furniture part list for guidance.
 Be sure all parts are complete before assembly. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched.
 Follow the figure to start assembling.

CAUTION : 1. Do not FULLY - TIGHTEN the nuts or nuts bolts until they are ready for assembly.
 2. Do not OVER - TIGHTEN the nuts or bolts to avoid causing damages to the thread.
 3. Keep all hardware parts out of reach of children.


NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tools needed : Screwdriver (not provided).


PART LIST			
ITEM	DESCRIPTION	BOX	QTY
A	BACK	1	1 PC
B	SEAT	1	1 PC
C	ARM	1	2 PCS
D	SUPPORT RAIL	1	2 PCS
E	CUHSION	1	1 PC

HARDWARE LIST (BOX : 1)		
ITEM	DESCRIPTION	QTY
1	JCBC BOLT M6 x 50mm 	8 PCS
2	JCBC BOLT M6 x 40mm 	2 PCS
3	M6 SPRING WASHER 	10 PCS
4	WOOD DOWEL M8 x 30mm 	6 PCS
5	M4 ALLEN KEY (BALL SHAPE) 	1 PC

STEP 1




STEP 2




ASSEMBLY INSTRUCTIONS


STEP 3




STEP 4



STEP 5




STEP 6





ASSEMBLY INSTRUCTIONS

STEP 7




STEP 8

Don't screw tight



STEP 9



STEP 9.1


STEP 9.2

Don't screw tight

Don't screw tight

STEP 10

Place the chair on the flat surface and adjust the alignment and balance of the legs then , Please screw tight the steps 4 , 6 , 8 & 9 bolts.




ASSEMBLY INSTRUCTIONS



4 OF 4

STEP 11


STEP 11.1




STEP 11.2




STEP 12




STEP 13



STEP 13.1



STEP 13.2



STEP 14

