

Safety Precautions

- Read all safety precautions and installation instructions carefully before installing or servicing this fixture. Failure to comply with these instructions could result in potentially fatal electric shock and/or property damage.
- It is recommended that a qualified electrician perform all wiring. This fixture must be wired in accordance with all national and local electrical codes.
- Do not handle any energized fixture or attempt to energize any fixture with wet hands or while standing on a wet or damp surface or in water.
- This fixture is designed for use in a 120-277V AC, 60Hz fused circuit. This fixture is compatible with 0-10 V dimmers.
- Make sure that the power source conforms to the requirements of the fixture. (See labels on fixture housing)
- To reduce the risk of electrical shock, and to assure proper operation, this fixture must be adequately grounded. To accomplish proper grounding, there must be a separate ground wire (green) contact between this fixture and the ground connection of your main power supply panel.
- This fixture is intended to be used for general indoor lighting in dry or damp locations.
- Disclaimer:
 Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules and Canadian ICES-005 (B) / NMB-005 (B). These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiver antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult with the dealer or an experienced radio/TV technician for help.

Any modifications to this fixture may void the warranty and interfere with the safe operation of the luminaire. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Assembly Instructions

Step 1 – Preparing for installation

- Disconnect electrical power at fuse or circuit breaker box before installing or servicing any part of this fixture.
- Carefully remove the fixture from the carton, remove components from hardware kit.
- Remove wire way cover (4) from channel (5) by removing 2 screws (3).
- Remove the appropriate knockout(s) in channel (5) for power supply entry.
- Install junction box cover plate (6) to junction box (not provided) with two #8 screws (7).

Step 2 – Fixture mounting

- To locate, hold channel (5) up to the wall with power supply knockout located over entryway for power supply wires. Mark the locations of the mounting holes on the wall. Take the channel down and punch a small hole into the wall at each location using a nail or an awl to see if there is a wood stud. If there is a joist use a suitable wood screw (not included) to mount the channel. Where there is no stud to screw into, use a drywall anchor (not included) of suitable length to mount channel securely to the wall.
- Feed the black and white supply wires, and the green ground wire into the fixture through the open knockout hole. At this time you can finish mounting the channel to the wall

Wiring – All wiring must take place inside junction box (not included)

Caution: Make sure power is off at fuse or circuit breaker box. Check power wires for damage or scrapes. If power supply wires are within three inches of the LED driver, use wire suitable for at least 90°C (194°F).
Note: Most dwellings built before 1985 have supply wire rated to 60°C. Consult a qualified electrician before installing.

Step 3 – Wiring fixture

- Make all wire connections to appropriate wire using wire connectors.
- Connect the green wire (8) from the fixture to the supply power source ground wire.
- Connect the black wire from the fixture to the black (L) wire from supply power source.
- Connect the white wire from the fixture to the white (N) wire from supply power source.
- Pull on each wire lead to make sure connections are secure. Make certain no bare wires are exposed outside of wire connectors. Tuck all connections neatly into the junction box.
- Connect the LEDs to the driver by plugging the connector ends (9) together. Install wire way cover (4) by placing it over the channel and fastening with two screws (3).



Step 4 – Color Changing Temperature Adjustment, CCT (if desired)

- Set the two switches on each LED strip for the desired color temperature as shown in the above illustration. All boards must be set the same way. Note: fixture is preset to 3500K from factory.

Step 5 – Mounting

- Mark the center locations of the smaller holes through the two keyhole slots on the cabinet where you want to install.
- Take the fixture down and drill two small pilot holes at each location. Install two wood screws (3) into previously drilled holes but leave a 1/8 inch gap between the screw head and cabinet.
- Place the channel up against the cabinet with the screws passing through the larger hole of the keyhole slot, and then slide it over to the smaller holes.
- Secure the channel by tightening the two screws (3).
- Install the cover (2) by inserting the front into the 3 tabs on the channel (4) and squeezing until the all retaining tabs are engaged and locked securely.
- Install the diffuser by latching the U-groove shape onto the edge of the cover along with the edge of the channel.

Step 6 – Restore power at fuse or circuit breaker box



Limited Factory Warranty

AFX Inc. hereby warrants that this fixture is free from defects in materials and workmanship when installed and used under normal operating conditions for a period of 5 years from date of shipment from factory. This warranty covers all component parts and extends only to replacement of defective fixture or components; it does not cover failure due to improper installation, misuse, mishandling or damage incurred in transit.