

# **ASSEMBLY INSTRUCTIONS**

**Description: Oslo Dining Chair** 

## Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

### Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

#### Parts List

| Item | Description      |          | QTY |
|------|------------------|----------|-----|
| P1   | Left Side Frame  |          | 1   |
| P2   | Right Side Frame | <b>S</b> | 1   |
| P3   | Back Panel       |          | 1   |
| P4   | Seat Panel       | P4       | 1   |
| P5   | Stretchers       | / P5     | 2   |



## Hardware List

| Item | Description                   |   | QTY |
|------|-------------------------------|---|-----|
| H1   | Long Bolts Ø1/4"*2-1/2"       | 9 | 4   |
| H2   | Short Bolts Ø1/4"*1-1/2"      | 9 | 8   |
| Н3   | Lock Washers Ø1/4"            | 0 | 12  |
| H4   | Big Flat Washers Ø1/4"x19mm   | 0 | 4   |
| H5   | Small Flat Washers Ø1/4"x12mm | 0 | 8   |
| Н6   | Allen Wrench 1/4"             |   | 1   |
| H7   | Wooden Plugs                  | 0 | 8   |
| •    |                               |   |     |

### DISCLAIMER:

WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

### **Assembly Procedures:**

Step 1: Assemble the chair on a flat and soft surface either on a carpet or cloth to prevent the finish from scratching. Attach the back panel (P3) and stretchers (P5) to the right side frame (P2) as shown.



