Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provider).

PART LIST			
ITEM	DESCRIPTION	QTY	
Α	HEADBOARD	1 PC	
В	FOOTBOARD	1 PC	
C	SIDE RAIL	2 PCS	
D	CENTER RAIL	1 PC	
E	CENTER SUPPORT LEG	3 PCS	
F	CENTER SUPPORT	2 PCS	
G	BED SLAT	26 PCS	
Н	BED LEG	4 PCS	

HARDWARE LIST			
ITEM	DESCRIPTION	QTY	
1	WOOD SCREW M4 x 20mm	2 PCS	
2	WOOD SCREW M3.5 x 16mm	8 PCS	
3	PVC BLACK WASHER	4 PCS	
4	BED SLAT SIDE FITTER	26 PCS	
5	BED SLAT CENTRE FITTER	13 PCS	
6	M5 ALLEN KEY (BALL SHAPE)	1 PC	



