### **ASSEMBLY INSTRUCTION**



# **SUNPAN**

Sunpan Product Name: TIERRA BED - KING

Please visit our website **www.sunpan.com** for more great products


For assembly questions please call 1-800-787-1019 (or +1-416-736-0094) outside North America or email to info@sunpan.com

PARTS LIST  Before you begin, please layout all parts and ensure you have the correct count.					
PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION		
A	Headboard	1			
В	Footboard	1			
С	Round Wooden Legs Support	2			
D	Meltal Legs	4			
E	Side Rails	2	1/5		

F	Center Rails	2	CHARLAND CONTRACTOR OF THE PARTY OF THE PART
G	Center Legs	6	
Н	Slats	10	
I	Bolts (6*20)	16	
J	Bolts (8*35)	10	
К	Screws (4*30mm)	4	
L	Screws (4*50mm)	4	<======================================
М	Allen Key M4	1	
N	Allen Key M5	1	

## ASSEMBLY INSTRUCTIONS

STEPS	DESCRIPTION	ILLUSTRATION
1	Attach the Round Wooden Legs (C) to Heahboard (A) by turning to tighten all.  Attach Metal Legs (D) to the Headboard (A) with Blot (I) using Allen Key M4 (M).	
2	Attach Metal Legs (D) to the Footboard (B) with Bolt (I) using Allen Key M4 (M).	
3	Secure Center Legs (G) to the Center Rail (F) with Bolts (J) attached on Center rail (F) using Allenkey M4 (M).	J G ADJUSTABLE



#### **ASSEMBLY TIPS:**

Please check parts and hardware before assembling. Follow each instruction step by step.

Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.

Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.

Please follow instructions in the sequence as numbered to assure fast/easy assembly.

#### **WARNING:**

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement. Keep all hardware parts out of the reach of children.

#### **FURNITURE CARE:**

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:

Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.

Excessive exposure to sunlight may cause fading.

Excessive temperature and humidity or cold may cause cracking or splitting.

Dust with a clean, damp, lint free cloth.

Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.

Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.