


CONVENIENCE CONCEPTS

DESIGNS2GO 3 TIER WIDE TV STAND



ASSEMBLY INSTRUCTIONS

We have designed our furniture with you , the customer in mind . Our clear , easy to follow , step by step instructions will guide you through the project from start to finish . Feel confident that this will be a fun and rewarding project . The final product will be a quality piece of furniture that will go together smoothly and give years of enjoyment .








Please do not return to the store

Broken or missing parts?





Need help with assembly?

If you have any questions just call 1-800-468-6447 or email us at parts@convenience-concepts.com


Hardware List

A 	B 	C 	D 	E 
End cap (5pcs)	Plastic foot (5pcs)	Plastic anchor (2pcs)	Cable tie (2pcs)	Eyelet screw (2pcs)

Panel List

1  Front	2  Front
Top / Bottom shelf (2pcs)	Middle shelf (1pc)
3 	4 
Long metal pole (5pcs)	Short metal pole (5pcs)

Exploded Views




Step 1

1. Place bottom shelf **1** over plastic feet (B).
2. Gently screw long poles **3** into feet (B) using care not to over tighten.

B




x5





Step 2

1. Place middle shelf **2** over long poles **3**.
2. Gently screw short poles **4** into long poles **3**. Be careful not to over tighten.



Step 3

1. Place top shelf **1** onto short poles **4**.
2. Attach end caps(A) to unit by turning in a clockwise direction into short poles **4**.



Step 4

1. Drill holes slightly smaller than anchors (C) into drywall and gently tap anchors into holes.
2. Insert eyelet screws (E) into anchors and fasten unit to wall using cable ties (D).

