


## **MODERN TV STAND WITH STORAGE**

# MODEL RTA-8850 ASSEMBLY INSTRUCTIONS

REV-FP-6-8273-0724



Thank you for purchasing our product



Do a quick inventory of all the parts and hardware listed below.




For Support, assembly questions & Replacement Parts within the 48 Contiguous United States:

Please email us at: support@rtaproducts.com




Replacement Parts for International
Customers & **AK-HI-PR** orders:
RTA Products will replace the part free of charge, while the customer is responsible for shipping costs plus any International local taxes or duties.

## **MAIN PARTS LIST**



# MAIN PARTS LAYOUT (For reference)



# HARDWARE LIST AND INCLUDED TOOLS

PART	QTY	SIZE / DESCRIPTION	ITEM
1	24	Ø8x25 Wooden Dowel	0 10 20 30 40 50 60
2	8 Pairs	Cam lock and M6x32 bolt	(a) 10 20 30 40 50 60
3	20	M3.5x16	<b>⊕</b> □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
4	6	M4X65	① 10 20 30 40 50 60
5	50	20mm Nail	0=
6	4	M6x22 Double metal pin	0 10 20 30 40 50 60
7	4	Plastic door stopper	
8	5	50x50x40mm Plastic foot	
9	4 Sets	Magnet and screw	(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)

TOOLS REQUIRED BUT NOT INCLUDED				
1	Phillips Screwdriver			
1	Hammer			
1	Mallet	A		

If you will use a power driver:

- Make sure to have the appropriate Phillips bits.
- Start using at a low torque or speed to avoid stripping the screws.



#### BEFORE YOU START THE ASSEMBLY, PLEASE READ THE FOLLOWING TIPS AND WARNINGS.

- Do not discard this manual or any of the packaging material until the unit is completely assembled.
- Please read the assembly instructions throughly and follow step by step.








• The assembly might require of 2 persons for certain steps. Before you start the installation, make sure there is someone else nearby to help you.




 Make sure you understand which hardware will be used on each step. Using the wrong size of screw, bolt or pin might strip the threads or cause damage to the part in which it is being used.






- To avoid misalignments, always leave the screws loosely and do not tighten them until all the pieces are positioned correctly.
- Do not overtighten or force the screws as they might break, strip, damage the threads of the holes, or get stuck inside the parts.



 If the hole seems to small for the screw, make sure you are using the correct size of screw and/or that you are installing it in the correct hole.



 Sometimes on the wood panels the laminate or material might be covering the hole partially or entirely, if there is no visible hole or if it looks too small, pass and press the tip of your finger over the area to feel its indentation, and carefully pierce the laminate to uncover the hole underneath.



 Please be kind to our planet, when done with the assembly, recycle any of the packaging materials that is accepted by your city or recycling service.






## **ASSEMBLY STEPS**

NOTES: • The product will start assembling with its front facing down the floor.


• Work over carpeting or use blankets to protect the panels' surfaces.



# RTA-8850


**P.5** 






## THEN: Attach B to F

NOTE: B will stay temporarily attached to F with just the dowels.







## FIRST: Install dowels #1 into the indicated holes on panels A, C and D.



THEN: Install the stoppers #7 to panels A, C and D positioned as shown.











FIRST: Attach to the door panels I the pins #6 at the top and the magnet screws #9 at the bottom.





THEN: Assemble panel C to H with cam locks #2.




THEN: Install one of door panel I facing down and into the groove of panel C.


LAST: Install panel A to panel B in the indicated postion and orientation.








FIRST: Install the second door panel I facing down and into the groove of panel A.




THEN: Assemble left panel D to panel H with cam lock #2.




P.8


# RTA-8850

**P.8** 





FIRST: Remove the bottom cap from the plastic feet #8.






LAST: Attach the magnets #9 to the top surface of panel E along the front edge.







## **TIP-OVER WARNING!**

Always pay close attention to small children playing near the unit or if they are watching TV very close to it to prevent tip-over accidents.







#### **NOTICE**

• The warranty does not extend to regular wear and tear, nor the manufacturer assumes liability for damages or consequences due to accidents, incorrect assembly, negligence, improper use, modifications, or not heeding the above warnings.

### **TECHNI MOBILI WARRANTY**



TV Stand: 2 YEAR WARRANTY

RTA Products, LLC warrants to the Original Purchaser who acquired a new product from RTA Products or its authorized resellers that this product will be free from defects in its workmanship and materials, under normal use and service conditions, as described herein. "Defects" as used in this warranty, is defined as any imperfections that impair the use of the furniture or product. RTA products will repair or replace, at is option, without charge to the original purchaser 'other than freight from purchaser to RTA Products, only the defective products or parts for a period of TWO (2) Years.

Replacement parts can only be supplied if parts are available. Items out of production may be unavailable. This warranty will be effective for the applicable time period beginning the date of purchase on your original sales receipt. RTA product's obligation under this warranty is limited to repairing or replacing products or parts as provided herein. This product has been designed for and is intended for office and home-office use only. This warranty is Original Purchaser's sole remedy for product defects, and this warranty does not extend to any product, or damage to any product, caused by or attributed to abuse or misuse, products used for commercial or rental purposes, use modifications of, or attachments to the product, and products or parts not used, maintained, or extended hereunder is in lieu of any and all other warranties, express or implied, including without limitations any implied warranty or merchantability or of fitness for a particular purpose. Please note, all desks made with PVC Laminate surface should not be exposed to direct sunlight, as it may damage the material. Damage of this nature is not covered under this warranty.

RTA Products will not be responsible for indirect, special, incidental or consequential damages. This warranty is limited to merchandise purchased in the Continental United States, excludes AK, HI and PR. Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights. You may also have other rights that may vary from state to state.

To file a Claim within the 48 contiguous United States: Email us to warranty@rtaproducts.com to explain the defect and provide your name, address, phone number, model number of our product, date and place, and proof of purchase. Please provide pictures of the damage or defect.

If we determine that a replacement will remedy the situation, and in order to determine the extent or the cause of the defect, purchaser may be requested to send the part in question at purchaser's expense. Once we receive the part, we will examine it and determine whether the claim is valid (or not), and then proceed to send the replacement. We will ship the replacement at our expense.

#### Replacement Parts for International Customers & AK-HI-PR orders:

RTA Products will replace the part free of charge, while the customer is responsible for shipping costs plus any International local taxes or duties.