# **User's Manual**



# **INSTALLATION INSTRUCTIONS**

# **Installation Manual**





# **BEFORE INSTALLATION**

S.N.	Name	Qty
1	Handle	2
2	Valve	1
3	Spout	1
4	Tool Kit	1



Operating conditions:

- 1. Recommended flow temperature ≤ 65°C,Maximum flow temperature ≤ 90°C
- 2. Minimum flow pressure 1 bar, Maximum flow pressure 5 bar
- 3. Recommended operating pressure 3 bar

4. At a resting pressure above 5 bar, a pressure reducer in accordance with DIN 1988 must be installed in the supply line to maintain noise levels in accordance with DIN 4109.

Precautions:

- 1. Before installing the faucet, be sure to remove the impurities and sludge in the embedded water pipe.
- 2. After installation, please check whether the connections are tightly connected and whether the pipeline leaks.
- 3. When using, make sure that the water inlet hose cannot be twisted to prevent the hose from rupturing.



#### Check accessories

Standard List of Accessories:

When you open the product packaging, please check whether the objects in it are consistent with the main body and accessories you purchased. If there is any inconsistency, please contact our company or our distributor.

Note: 1.Accessories are subject to change without prior notice if the change does not affect usage;

2. The appearance of the product is subject to the physical objects you receive, and the schematic diagram is only for reference.

# **INSTALLATION STEPS**

This product has been inspected and debugged by the factory to the best condition. Please do not disassemble and assemble it yourself.



Before installing the product, please be sure to remove sundries and sludge from the water pipe to prevent sundries from blocking the product.





1. Make a groove in the wall as shown, the depth must be be consistent with the valve body, refer to the real item. Connect the pipes when embedding the valve, and check if there is any leakage.



2. Seal the wall, and unscrew the spout as the picture shown.



3. Install the part as the picture shown. Test to see if there is leakage after completing the installation steps above.



4. Faucet should be like this when everything is done.



Operation guide for handles.

### **INSTALLATION DIMENSION**



#### **CLEANING CARE**

In order to keep the appearance of product clean, bright and good

performance, please take care of the product as follows;

1. Rinse with water only and dry with soff cotton cloth;

2.Use mild liquid and colorless glass cleaner to remove surface dirt and scale film, or use polish without abrasive effect;

3.Do not use abrasive deterfgent, polish, emery cloth, paper towel or scraper, etc;

4.Do not use acid cleaner, or cleaner and soap with insoluble gran etc;

5.In the process of use, mud my accumulate in the bubbler and make the water flow show,

The bubbler can be unscrewed, rinsed with water, and then installed back in place.



